

Gen 7 XXL Tank Drilling Instructions

Important: Please read through all instructions fully before starting.

Step 1: Remove the Plug

- Begin by safely removing any existing plug or cap from the tank to allow access to the area you'll be drilling.

Step 2: Set Up a System to Catch Shavings

- To prevent debris from entering the tank and causing damage, set up a system to catch the plastic shavings. Options could include:
 - Placing a rag or cloth inside the tank to catch the shavings.
 - Using a vacuum with a hose directed at the drilling site to suck up the shavings as you work.

Step 3: Drill the Holes

- Start with a small pilot drill bit, and gradually increase the drill bit size to achieve the desired hole diameter. A small amount of grease on the drill bit can catch some of the plastic shavings from falling into the tank.
- Be careful to drill as large as possible without damaging the threads or surrounding plastic. Take your time, and avoid contacting the threads.
- Be careful to drill only the necessary holes for the intended kit.



Fast Fill Kit



Universal Pickup Tube and Return System

Step 4: Trim the Inside of the Holes

- After drilling, use a razor blade or utility knife to carefully trim the inside of the hole, ensuring it's flush with the threads. This step helps smooth out any rough edges and ensures a clean fit for the fittings.

Step 5: Clean the Tank

- Once you've finished drilling and trimming, carefully remove all plastic shavings from inside the tank. Use compressed air, a vacuum, or a damp cloth to ensure the tank is completely free of debris. This is crucial to avoid any plastic pieces entering the fuel system, as they could cause damage or clog components.

Gen 7 Fast Fill Vent Kit (9901770) Install

Step 1: Drill Out Holes

- Follow the drilling instructions above carefully.

Step 2: Apply Thread Seal Tape

- wrap the threads of the valve in thread seal tape (Teflon tape).

Step 3: Thread valve into tank

- Carefully thread the roller valve into the tank, ensuring you do not cross-thread it.



Step 4: Check valve hoses

- Ensure rubber hoses connected to valves are angled upwards with no dips or sags. A zip tie may be used to secure valve hoses in an upward position.

Warranty is void if product is improperly installed.
For questions or customer service call (800) 728-4982

TITAN Fuel Tanks

P.O. Box 2225

Idaho Falls, ID 83403 USA

Telephone (208) 522-1325, FAX (208) 529-2162

www.titanfueltanks.com

TITAN Fuel Tanks are PROUDLY MADE IN THE USA

Revised 4.21.25

©2025 Supertanks, LLC

